

Nikon Digiscoping System Diagram



Fieldscopes

III / III A / ED III / ED III A / ED82 / ED82 A

ED78 series, II series and I series can also be used (I series can be used only with 24x/30x Wide MC and Fieldscope Digital SLR Camera Attachment FSA-L1).

We strongly recommend using an ED-type model, which employs ED glass to minimise chromatic aberration and keep images sharp.



Fieldscope Digital SLR Camera Attachment FSA-L1



Digital SLR Cameras

D2x D2^{ts} D2H
D1x D1H D1
D100 D70s D70 D50



Wide DS Fieldscope Eyepieces

24x/30x Wide DS
40x/50x Wide DS
60x/75x Wide DS



FSA-1



MC Fieldscope Eyepieces

24x/30x Wide MC
30x/38x Wide MC
40x/50x Wide MC
60x/75x Wide MC
20-60x/25-75x MC II Zoom



FSA-2

Digital Camera Attachment



FSA-3

Attachment rings



F-CP885
for COOLPIX 4300 series and 885



F/S-CP9XX
for COOLPIX
900 series and 4500



F-CP880
for COOLPIX 880



F-CP5000
for COOLPIX 5000



Fieldscope Digital Camera Bracket FSB-1A



Digital Cameras

COOLPIX 7900
COOLPIX 5200
COOLPIX 4200



Fieldscope Digital Camera Bracket FSB-2



Digital Cameras

COOLPIX 5600
COOLPIX 4600



Digital Cameras

COOLPIX 4500
COOLPIX 4300
COOLPIX 900 series, 880 series and 5000
can also be used.



Note : The FSA-1, 2 set and FSA-3 are sold separately.